

Vacuum Solutions

Application Support

Service



LEYBOLD VACUUM

GA 05.136/2.02



SERVICE OF VACUUM PUMP SYSTEMS
2442 Etnick Blvd. Bethlehem, PA 18020
For Service Call (610) 625-1505
www.polvac.com



MAG W 2010 C

Turbomolecular Pump
with Magnetic Bearing

MAG.DRIVE 2000

Electronic Frequency
Converter

Software version 1.4.xx

Cat. Nos.
121 32
121 35 /36

Operating Instructions

Contents	Page
1 Description	3
1.1 System overview	3
1.2 Compatibility with pumped media	3
1.3 Design of the MAG	3
1.4 Function and design of the MAG.DRIVE	4
1.5 Standard specification	6
1.6 Technical data	6
1.7 Ordering information	7
2 Installation	11
2.1 General safety information	11
2.2 Unpacking - storing - transportation	11
2.3 Operating environment	12
2.4 Connecting the MAG to the vacuum chamber	12
2.5 Connecting the backing pump	16
2.6 Connecting the cooling water	18
2.7 Connecting the purge gas	19
2.8 Installing the MAG.DRIVE	20
2.8.1 Power supply connection X10	20
2.8.2 Pump connection	21
2.8.3 Control plug X14	21
2.8.4 Interface connector	24
3 Operation	25
3.1 General operation rules	25
3.2 Operation with the START and STOP keys	26
3.3 Remote control	27
4 Plug-in Control	28
4.1 Operation with plug-in control	28
4.2 Operating statuses	30
4.3 Operating menu	32
4.3.1 Basic menu	32
4.3.2 Settings converter	33
4.3.3 Settings pump	34
4.3.6 Total view of the menu	35
5 Maintenance	36
5.1 Removing the pump from the system	36
5.2 Service at Leybold's	37
6 Troubleshooting	38
6.1 Warning messages	39
6.2 Failure messages	40
6.3 Malfunctions	43
Certifications	44
Forms	48

Figures

The references to diagrams, e. g. (1/2) consist of the Fig. No. and the Item No. in that order.

We reserve the right to alter the design or any data given in these Operating Instructions. The illustrations are not binding.

The Operating Instructions are included with the pump **and** the converter. If they have different editions, the version delivered with the pump describes the pump correctly and the version delivered with the converter describes the converter correctly. The version number is the digit behind the „/“ in the GA No.. Example: GA 05.136/1.02 is the first edition.

Differences between the versions:

/1 → /2

- We corrected the dimensional drawings and the drawings for the purge gas connector.
- We changed some ordering data.
- We added information for fastening the vacuum chamber.
- We added certifications concerning EC directives.
- We corrected some minor mistakes.

Thus, you may use version /2 instead of version /1.

See also the last page.

1 Description

1.1 System overview

The Leybold **MAG** pumping system consists of:

- The **MAG W 2010 C** turbopump

The MAG are turbomolecular pumps utilizing magnetic bearings. They are designed to evacuate vacuum chambers down to pressure values in the high-vacuum range and to pump high gas throughputs.

- The **MAG.DRIVE 2000** frequency converter

The electronic converter converts the single-phase line supply voltage into a three-phase DC voltage to drive the pump motor. It also evaluates measured signals and controls

- the pump functions and
- the active magnetic bearing system

The MAG.DRIVE 2000 can be operated with the START and STOP keys, via a plug-in control, via a serial interface, or via a DeviceNet interface.

- A **cable set** consisting of:
 - BEARING cable
 - DRIVE cable

1.2 Compatibility with pumped media

The MAG W 2010 C is specifically designed for the needs of the semiconductor industry.

Corrosion protection

To protect the pump from corrosive gases it is mandatory to use dry Nitrogen purge during operation of the pump. The purge gas protects the bearing section and the motor from corrosive gases.

The rotor and the stator of the pump are KEPLA®-coated to prevent corrosive attack caused by the process gases. The corrosion protection of the pump is effective only when the pump is protected from moisture during standstill and storage. If the process gas contains moisture, contact Leybold for recommendations.

Caution

The pump cannot handle gases or media (e.g. AlCl_3) which form deposits inside the pump.

Ignition danger

During operation the pressure inside the MAG is so low that there is no danger of ignition (at pressures below about 100 mbar). A hazardous condition will be created if flammable mixtures enter the hot pump at pressures above 100 mbar. During operation the pump can reach temperatures as high as 120°C (248°F). If the pump is damaged, sparks could occur which could ignite explosive mixtures.

Please consult Leybold regarding the media which can safely be handled with this unit, with or without purge gas.

1.3 Design of the MAG

The MAG comprises basically the pump housing, the multistage rotor with the stator package, the drive, and a magnetic bearing.

Rotor

The rotor is made from a high strength aluminium alloy. The rotor and the lower stator plates are protected with a special ceramic layer (KEPLA-COAT®). The rotor is a multi-stage axial-flow turbine. In addition to the turbine stage it has a screw stage.

The rotor is machined from one piece and the geometry of the blades is optimized for high compression and pumping speed of the typical gases used in semiconductor manufacturing processes (e.g. SF_6 , Ar, BCl_3).

Bearings

The MAG has a built-in precision 5-axis controlled magnetic bearing. The rotor is suspended by trouble-free magnets:

- along two orthogonal axes in each of two radial planes
- and completely in the axial direction

The bearing concept allows for low vibration operations and insures operation of the pump in any mounting position. Magnetic bearings also guarantee ultra-clean vacuum because no grease is used for lubrication of bearings.

Two touch down bearings are provided to stabilize the rotor mechanically if impacts occur during operation. They are only used in case of the breaking of the power supply or BEARING cable during operation, strong shocks, or faulty electronics.

Motor and control

A DC motor without commutator is used to power the rotor.

Drive voltage for the motor and the operating voltage for the magnetic bearing are supplied by the MAG.DRIVE frequency converter. It also handles the automatic monitoring of these systems.

The pump is equipped with a data storage device which stores the important operating parameters during the complete operation time of the pump.

The converter monitors continuously all important operating parameters and provides warning and alarm signals in case the operating conditions exceed the specification or the set threshold.

1.4 Function and design of the MAG.DRIVE

The MAG.DRIVE 2000 electronic converter is used to drive the MAG turbo-molecular pumps.

The electronic converter converts the single-phase line supply voltage into a three-phase DC voltage to control and monitor the electronically-commutated DC motor. It also evaluates measured signals and controls (open-loop and closed-loop) the pump functions.

The magnetic bearing control system is integrated into the converter. It actively controls the pump rotor in five axes (closed-loop control).

All parameters required for pump operation and the listed faults and operating hours are stored in a non-volatile memory in the pump. When the converter is switched on, the data are loaded into the converter from the pump.

The outputs of the electronic converter are no-load and short-circuit proof.

For remote control via control connector X14 we recommend that either a relay or optocoupler is used to provide electrical decoupling.

Housing

The converter is supplied with a closed housing. It can be installed in a 19" cabinet; see Section 2.8.

Front panel

Main switch

9-pin connecting socket for the plug-in control or for connection of a serial interface

2 short-stroke keys

1 green/red STATUS LED

1 green COM LED (communications interface)

1 green MAIN LED (line supply voltage)

2 fuses TMS (Temperature Management System; no function when operating a MAG W 2010 C)

The optional plug-in control has 10 keys and 1 backlit LCD with 2 lines, each 16 characters. The plug-in control displays operating statuses and failures and allows the configuration of the pumping system.

Rear panel


X14 50-pin D socket connector for remote monitoring and open-loop control

X19 3-pin Hirschmann connector for the connection to the mains supply


X20 55-pin MIL standard socket connector for internal sensors and magnetic bearing connection

X21 41-pin MIL standard socket connector for the motor, TMS, and purge valve connection

Spare slot for optional network cards



MAG.DRIVE 2000



MAG.DRIVE 2000 with plug-in control

Fig. 1 Front panel

- X14 Connection control plug
- X19 Mains connection
- X20 Connection magnetic bearing
- X21 Connection pump motor and TMS




Fig.2 Rear panel with connections

1.5 Standard specification

MAG

The turbomolecular pumps are shipped complete, sealed in a PE bag containing a desiccant. The maximum effective life time of the desiccant is one year.

The intake flange is sealed with a transport seal, the forevacuum flange with a plastic cap.

For the intake flange, a centering ring with FPM O-ring, outer ring, and a splinter guard are enclosed. For the cooling water inlet a blind plug is enclosed.

We also provide the bolts for attaching the pump to your tool. To avoid any safety risk we highly recommend using only the bolts provided with the pump. Refer also to Section 2.4 „Connecting the MAG ...“.

The electronic frequency converter MAG DRIVE as well as the cables required for operation must be **ordered seperately**.

In addition, a seal kit is included to seal the pump tightly if it is removed from the process.

MAG.DRIVE

- Converter
- Line supply cable with USA connector, approx. 3m
- Line supply cable with EURO connector, approx. 3 m
- 2 spare fuses for the TMS (miniature fuses 5 x 20 mm, F4A; according to IEC 127-2/1) and 2 fuse holders 6.3 x 30 mm
- Plug for control plug X14

Cable Set

- BEARING cable
- DRIVE/TMS cable

1.6 Technical data

MAG W 2010 C

Pumping speed for N ₂ measured with splinter guard (PNEUROP)	1650 l·s ⁻¹
Gas flow (continuous operation with Argon)	1000 sccm
Compression for N ₂	>10 ⁸
Ultimate pressure as to DIN 28 400	< 10 ⁻⁸ mbar
Max. forevacuum pressure with Nitrogen	3.3 mbar
with Argon	4.1 mbar
Rotor Speed	28,800 min ⁻¹
Run-up time	< 10 min
Braking time with/without venting	1 / < 7.5 min
Cooling	water
Cooling connection, Push-on connector Swagelok	
tube outlet connector	1/2"
tube inlet connector	2 x 3/8"
Cooling water temperature	15 to 30 °C 59 to 86 °F
Base flange temperature (depending on the load)	30 to 50 °C 86 to 122 °F
Weight	approx. 65 kg
High-vacuum connection flange	DN 250 ISO-F
Forevacuum connection flange	DN 40 KF
Recommended backing pump	DRYVAC 50
Admissible ambient temperature	5 to 40 °C 40 to 104 °F
Storage temperature	-10 to +60 °C 14 to 140 °F
Max. relative air humidity	95% (non-condensing)
Degree of protection (EN 60529)	IP 20

Purge Gas

Purge gas:	dry nitrogen, argon or similar
Purge gas throughput	0.5 to 0.65 mbar·l·s ⁻¹ 30 to 40 sccm
Connection: VCR Nut	1/4"

Technical data (continued)

MAG.DRIVE

Voltage range	200 - 240 V +10% -15%
Line supply frequency	50 / 60 Hz
Load	
Stand-by	approx. 100 W
Continuous (rated speed)	810 W
Maximum	1800 W
Max. voltage motor	60 V
Maximum pump current	20 A rms
Continuous pump current, max.	15 A rms
Maximum frequency	480 Hz
Load capability, relay output	42 V, 1 A
Temperature during operation	0-45° C
Storage temperature	- 10° C to + 60° C
Relative air humidity	Class F acc. to DIN 400 40
Weight	10 kg


The units have degree of protection IP20 in accordance with EN 60529

(protection against the ingress of solid foreign bodies > 12 mm diameter (finger). It is not protected against the ingress of water with damaging effects.)



An increased degree of protection, e.g. IP54 can only be implemented by mounting the converter in an additional housing.

1.7 Ordering data

			Order No.
MAG W 2010 C			121 32
Seal Kit DN 250			200 91 641
MAG.DRIVE 2000 converter			121 35
Plug-in control			121 36
MAG.DRIVE 2000 with DeviceNet			121 37
Connecting cables, converter / pump			
Length	Cable BEARING	Cable DRIVE/TMS	
1.5 m	121 29	121 30	
10 m	121 21	121 22	
20 m	121 25	121 26	
19" installation frame			161 00
Connector for hardware interface from 25 pins to 50 pins			on request
MAG.WIN, an operator control interface which can run under Windows with user instructions as Windows help			on request
Connecting cable serial interface (front panel, 9-pin D-connector), approx. 5 m long			on request



with cable length 1.5 m



with cable length 10 or 20 m





Fig. 3 Dimensional drawing of the MAG.DRIVE; dimensions in mm




Fig. 4 Pumping speed curve for Nitrogen




Fig. 5 MAG W 2010 C: operation diagram for nitrogen

Rotor speed 480 Hz
Purge gas flow 36 sccm Nitrogen
with splinter guard
Forepump D 65 B + WS 251
Pipe 1 m DN 40
according to PNEUROP




Fig. 6 MAG W 2010 C, Dimensions in mm

2 Installation

2.1 General safety information

Warning

Indicates procedures that must be strictly observed to prevent hazards to persons.

Caution

Indicates procedures that must be strictly observed to prevent damage to, or destruction of the MAG.

Warning



Never expose any parts of the body to the vacuum.

Warning



The converter has dangerous voltage levels.



Failure to strictly follow the instructions in this Manual can result in death, severe bodily injuries or significant material damage.

Only suitably qualified personnel are permitted to work on the pump or converter. Personnel must be completely knowledgeable of all warning information and measures which are specified in this Instruction manual for transporting, installing, and operating the unit.

Qualified personnel

Qualified electrical personnel in this instruction manual means a person who has received electrical engineering instruction or is an electrical expert in accordance with EN 60204, Part 1, 3.30 respectively 3.55.

Warning



The device contains electrostatically sensitive devices (ESD)!

Warning



Unauthorized opening of the converter voids the warranty.

Before opening the converter, always disconnect it from the mains and the pump!

Before disconnecting any cables make sure that the converter is switched off and the pump has come to a standstill.

When applying external voltage in excess of 42 V to terminals of the device, observe local safety regulations!

Unauthorized device conversion and modifications are prohibited for safety reasons.

Please keep this Operating Instruction for future reference.

2.2 Unpacking - storing - transportation

Remove the equipment from the transportation box and keep the packaging. Make sure that the product has not been damaged during transportation. If this unit is damaged contact your carrier and inform LEYBOLD if necessary. For storage of the product, use the packaging provided.

Lift the pump by the crane eyelets or move it with at least two persons.

You can position the pump on the base plate for transport with a lift-truck. Protect the pump against slipping and tipping over.


Caution

Be careful not to damage the sockets and coolant connections during transportation.

Do not stand below the pump while connecting or removing the MAG.

The MAG is shipped in a sealed PE bag with desiccant. Do not open the sealed package until immediately before installing.

Do not remove the covers and blanking flanges until you are ready to make the connections, to ensure that the MAG is installed under the cleanest possible conditions.



2.3 Operating environment

When using the MAG inside a magnetic field, the magnetic induction at the pump housing must not exceed 5 mT; (1 mT (milliTesla) = 10 G (Gauß))

Exceeding this limit can cause excessive rotor heating due to the eddy currents generated in this situation. It is therefore necessary to provide suitable shielding in such cases.

The standard version of the MAG is resistant to radiation at levels up to 10^3 Gy. (1 Gy (Gray) = 100 rad)

The ambient temperature must not exceed 40°C (104 °F).

The noise level when the pump is running is below 70 dB(A). No acoustic insulation is required.

2.4 Connecting the MAG to the vacuum chamber

The MAG is shipped in a sealed PE bag with desiccant. Do not open the package until immediately before installing.

Do not remove the covers and blanking flanges until you are ready to make the connections, to ensure that the MAG is installed under the cleanest possible conditions.

Pay attention to maximum cleanliness when connecting.

Remove the transport seal from the intake flange. To do so unscrew the screws (7/2) and remove the aluminum cover. We recommend saving the transport seal for maintenance.




Fig. 8 Connection elements




Fig. 9 Installing the splinter guard

Foreign objects entering the pump through the high-vacuum flange can cause serious damage to the rotor. That's why the splinter guard must always be installed.

Damages caused during operation without the splinter guard are excluded from warranty.

Caution

Install the splinter guard as shown in Fig. 9. Installing the splinter guard upside down may lead to contact between splinter guard and rotor during fast venting of the pump.




Fig. 10 Vacuum chamber fixed to the floor

Warning



The pump must be securely attached. If the pump should suddenly seize, inadequate attachment could cause the pump to break away or allow internal pump parts to be discharged. Never operate the pump (in bench tests, for instance) without its being connected at the vacuum chamber.

If the pump should suddenly seize, the deceleration torque of 60,000 Nm will have to be absorbed by the system. To accomplish this, use all 12 bolts provided by Leybold for fastening the high-vacuum flange; see also Fig. 11.

Mount the MAG as close as possible to the vacuum chamber. If the MAG is permanently flanged to a vacuum chamber with a weight exceeding 500 kg, it will not be necessary to secure it in any other way.

The vacuum chamber must be securely attached to the floor or a solid wall.

In case of lighter vacuum vessels secure the pump additionally. The pump's bottom is equipped with tapered holes for fastening a support; see Fig. 6.

If the pump is exposed to shocks, e.g. by a gate valve, secure the pump so that it is supported in the direction of the shock.

We recommend installing an isolation valve between the pump and the chamber. The valve should be closed during wet cleans of the chamber and in case of pump failures which will lead to a pump shut down. The valve should normally be closed with power off.




Fig. 11 Fixing the intake flange

Key to Fig. 12

- 1 Turbomolecular pump
- 2 Forevacuum gauge point
- 3 Backing pump
- 4 Anti-vibration bellows
- 5 Forevacuum valve
- 6 High vacuum valve
- 7 Purge gas connection
- 8 Valve in the roughing line
- 9 Electronic frequency converter

— — — — — roughing line; recommended if shorter cycle times are to be achieved

- - - - - DRIVE and BEARING cable




Fig. 12 Layout of a turbomolecular pump system

2.5 Connecting the backing pump

A two stage rotary vane pump or dry-compression backing pump is required to support operation of the MAG.

We recommend using the DRYVAC or our TRIVAC-B pump for this purpose.

In case of high gas throughput, it may also be necessary to use a roots blower to achieve the backing pressure necessary for operating the MAG. We recommend our RUVAC blower for this purpose or our DRYVAC 251/501 systems.

Fig. 12 shows schematically the design of a pump system incorporating a MAG with an additional foreline valve and an isolation valve between chamber and MAG.

The foreline isolation valve is recommended to protect the MAG from shock venting in case of uncontrolled shut down of the backing pump. This valve must be able to close fast enough to avoid pressure increase in the MAG.

In case of an oil-sealed backing pump the foreline isolation valve protects the MAG from backstreaming oil vapor during standstill.

Connect the forevacuum flange of the MAG to the backing pump.

The torque on the forevacuum connection flange must not exceed the values shown in Fig. 13.

Warning



The forevacuum line must be tight. Hazardous gases can escape at leaks or the gases being pumped can react with the air or humidity. We recommend a leak check.




Fig. 13 Maximum torques for the forevacuum connection and connecting the cooling water




Fig. 14 Recommended cooling water flow as a function of cooling water temperature

2.6 Connecting the cooling water

Cooling water specifications

Inlet temperature	15 - 30 °C
Max. inlet pressure	9 bar over atmosphere
Cooling water requirement	See Fig. 14
Appearance	Colorless, clear, free of oils and greases
Sediments	< 250 mg/l
Particle size	< 150 µm
Electrical conductivity	< 500 µS/cm
pH value	7 to 8.5
Overall hardness (total alkaline earths)	
max. 20 ° German hardness scale	
(= 3.57 mmol/l)	

Further information on request.

Connect the cooling water to the connectors; see Fig. 13. In case you want to use only 1 inlet connector close the other one with the blind plug provided with the pump.

Turn off the cooling water supply when the pump is switched off in order to avoid condensate formation in the pump.

If you do not close the cooling water it may take longer to achieve ultimate pressure after start up of the system.




Fig. 15 Connecting the purge gas

2.7 Connecting the purge gas

The MAG is equipped with a purge gas connector. To ensure protection of the pump a constant purge gas throughput of 30 to 40 sccm is required. You may use a flow controller to ensure the flow. Inadequate purge gas flow voids the warranty.

Connect purge gas to the VCR nut 1/4" as shown in Fig. 15.

Warning



Monitor the purge gas continuously.

Insufficient purge gas flow can result in:

- Process gases entering the motor and bearing area of the MAG
- Process gases escaping from the purge gas connector
- Humidity entering the pump.



2.8 Installing the MAG.DRIVE

The converter can be installed in a 19" cabinet. It is 1/2 of 19" wide and has 3 height units. For easier installation we offer an installation frame; see Section 1.7. If you use this installation frame, remove the converter's rubber feet when installing the converter.

Caution

In order to guarantee sufficient cooling, there must be a minimum clearance of 1 height unit (44.2 mm) at the bottom and 1 height unit at the top. During operation the temperature of the ambient air must not exceed 45 °C.

Warning



The pump may be operated only with a suitable frequency converter and a suitable connector cable.

Peak voltages of up to 130 V may be present at the connector line between the frequency converter and the pump; mains voltage is present at the heater.

Route all cables so as to protect them from damage.

The protection rating for the connectors is IP 30.

Do not expose the pump, the frequency converter or the connections to dripping water.

Install 16 A fuses for the converter.

Warning



Only adequately trained electrical/electronic personnel may connect-up the equipment in accordance with valid IEC (international), EN (European) and/or national guidelines, or under their management and supervision.

Caution

The connecting cables between the converters and pump may only be inserted or removed when the pump is switched off **and** stands still after the run-down procedure **and** the converter is isolated from the line supply.

If a connector is inserted or withdrawn when the converter is switched on or the pump is rotating, the converter and the pump could be damaged or destroyed!

Warning



Unauthorized opening of the converter voids the warranty.

Hazardous voltages are present inside the converter. Death or severe injury can occur if you come into contact with these hazardous voltages. Before opening the converter, isolate the converter from the line supply, and lock the switch so that it cannot be accidentally switched on again.

In addition the pump has to stand still because it works as generator as long as it rotates, and the pump cables have to be disconnected.

Installation instructions to maintain EMC

The MAG.DRIVE 2000 complies with the Electromagnetic Compatibility (EMC) Directives of the EC. In order to maintain this the following installation instructions must be observed:

- To connect the pump to the converter the prescribed Leybold cables must be used.
- The connection cables to the analog interface (control plug X14) and to the serial interface (connector X7) must be shielded. The shields must be connected to the metal housings of the SUB-D-connector and SUB-D-socket.

2.8.1 Power supply connection X19

The converter is ready to be connected to line supply voltages between 200-240 V 50/60 Hz. The connection is established using the power cable supplied, which is inserted at connector X19 at the rear of the converter.

Caution

The converter will be damaged if it is operated with the incorrect supply voltage.





Fig. 16 Block wiring diagram



1 = Phase L
2 = Not assigned
3 = Neutral N
S = PE

Fig. 17 Connector assignment X19, supply connection




Fig. 18 Control plug X14: Emergency off

2.8.2 Pump connection

Connect the converter (X20) to the magnetic bearing connection of the pump (X23) using the BEARING cable.

Connect the converter (X21) to the pump motor connection (X25) using the DRIVE/TMS cable. The TMS connection has no function and will be covered with a supplied cap.

Also refer to Fig. 16.

2.8.3 Control plug X14

Emergency off

Make sure that pins 47 and 48 are connected via a jumper if you don't connect an emergency off switch.

A plug for the control plug X14 with a jumper connected between pins 47 and 48 is included in the standard specification.

X14 50 pole Sub-D I/O

PIN SIGNAL

1	Relay 1 n.o.	FAILURE
2	Relay 2 n.o.	NORMAL OPERATION
3	Relay 3 n.o.	WARNING
4	Relay 4 n.o.	ACCELERATION
5	Relay 5 n.o.	DECELERATION
6	Relay 6 n.o.	OPTION1
7	Relay 7 n.o.	OPTION2
8	Relay 8 n.o.	OPTION3
9	Relay 9 n.o.	OPTION4
10	GND	
11	Dig. input	REMOTE/LOCAL
12	Dig. input	START/STOP
13	Dig. input	(TMS OFF)*
14	Dig. input	(PURGE GAS OFF)*
15		
16	Analog input 1	
17	Analog input 2	

18	Relay 1 com.	FAILURE
19	Relay 2 com.	NORMAL OPERATION
20	Relay 3 com.	WARNING
21	Relay 4 com.	ACCELERATION
22	Relay 5 com.	DECELERATION
23	Relay 6 com.	OPTION1
24	Relay 7 com.	OPTION2
25	Relay 8 com.	OPTION3
26	Relay 9 com.	OPTION4
27	GND	
28	+15V	
29	+15V	
30	GND	
31	GND	
32	Analog_GND	
33	Analog_GND	

34	Relay 1 n.c.	FAILURE
35	Relay 2 n.c.	NORMAL OPERATION
36	Relay 3 n.c.	WARNING
37	Relay 4 n.c.	ACCELERATION
38	Relay 5 n.c.	DECELERATION
39	Relay 6 n.c.	OPTION1
40	Relay 7 n.c.	OPTION2
41	Relay 8 n.c.	OPTION3
42	Relay 9 n.c.	OPTION4
43	GND	
44	Dig. input	(VENTING ON)*
45	Dig. input	Reserve
46	Dig. input	Reserve
47	Dig. input	EMERGENCY OFF
48	Dig. input	EMERGENCY OFF
49		
50	Analog output	

Fig. 19 Assignment control plug X14

* not used when operating a MAG 2010 C

Fig. 19 Assignment control plug X14

* not used when operating a MAG 2010 C

Relay outputs

The MAG.DRIVE 2000 converter has 9 relay outputs. They have changeover contacts. Five relay outputs are permanently assigned a signal.

Normal operation

Failure

Warning

Deceleration

Acceleration

The option relays can output one of the following signals:

Threshold bearing temperature reached

Threshold motor current reached

Threshold frequency reached

No cooling water

No purge gas

TMS temperature OK

Vent

Start command applied

Power supply O.K.

Pump standstill

Option relay 1 can store the selected signal. The option relays 2, 3, and 4 cannot store the selected signal permanently and change to the default setting after a power interruption. We recommend using only the default settings for the option relays 2, 3, and 4.

Option relay 2 Start command applied

Option relay 3 Power supply O.K.

Option relay 4 Pump standstill

The selection of signals for the option relay and the adjustment of their thresholds can be achieved via the operator control menu; see Section 4.3.2.

Analog output

The converter has an analog output which provides an analog signal (0..10 V) with a 10-bit resolution. The analog output function can be alternatively used to output

motor current

actual frequency

motor temperature

rotor displacement signals (PW24, PV13, PZ12)

The output value can be increased or reduced by a scale factor; see Section 4.3.2 Settings Converter.





Fig. 20 Function diagram outputs



- 1 +5V Power supply for plug-in control
- 2 TXD
- 3 RXD
- 4 n.c.
- 5 GND
- 6 -5V Power supply for plug-in control
- 7 Reset out for plug-in control
- 8 select plug-in control input
- 9 Boot input

Fig. 21 Connector assignment, interface X7 (front side)

Analog inputs

The converter has two analog inputs with a 10-bit resolution.

Input signal: 0...10V standard
 4...20mA on request

A supplementary function can be set for analog input 2 via the operator control menu; see Section 4.3.2:

No function: The input signal can be output via the serial interface.

Frequency setpoint: In addition to the function described above, the drive frequency setpoint is entered via analog input 2.

Digital inputs

The converter has 5 digital inputs with the following functions:

TMS OFF

Purge gas OFF

Vent ON

The functions are active if a High signal (15 V; e.g. Pins 28 or 29) is connected at the digital input.

Remote

Start (if Remote is active)

The functions Start and Remote are active if a Low signal (GND; e.g. Pins 27 or 43) is connected at the digital input.

2.8.4 Interface connector

A 9-pin sub-D socket is provided at the front panel to connect a higher-level open-loop control and monitoring unit or a PC with the MAG.WIN operator control program.

The connector X7 is assigned the serial interface RS 232.

Further information on the serial interface and the interface protocol to be used are provided in the optional manual „Serial interface MAG.DRIVE”.




Fig. 22 Curve for safe venting of the MAG; pressure rise as a function of venting time

3 Operation

3.1 General operation rules

The magnetic bearing in the MAG are immune to wear. In addition to the magnetic bearings, the MAG is equipped with touch-down bearings which protect the rotor against mechanical contact with the stator if the pump is subjected to external shock loading or when the pump is switched off. These touch-down bearings have a limited service life. Please observe the following in order to obtain maximum service life.

- Avoid shock and vibrations when the pump is running. Shocks perpendicular to the rotation axis are particularly harmful. If the pump appears to be running in the mechanical bearings continuously it is switched off.
- Do not suddenly expose the MAG to an already evacuated vacuum chamber. The pressure surge may cause the rotor to make contact with the touch-down bearings. This will cause increased wear.
- Do not disconnect the MAG and MAG.DRIVE while they are operating. If MAG and MAG.DRIVE have been disconnected accidentally re-connect them.
- When venting the MAG the values shown in the pressure rise curve must be maintained; see Fig. 22.

- Do not stop the MAG with the mains. Use the STOP key or a stop command. Switching off the mains while the pump is running will wear out the touch down bearings.

The pump may make noise during the run-up and run-down phases. This has neither an influence on the pump nor on the process.

Warning



Monitor the purge gas continuously.

Insufficient purge gas flow can result in:

- Process gases entering the motor and bearing area of the MAG
- Process gases escaping from the purge gas valve
- Humidity entering the pump.



Refer to Section 2.7.



3.2 Operation with the **START and STOP** keys

Switching on

- Switch on the MAG.DRIVE.

The MAIN LED lights green.

In case of corresponding connection the backing pump will be activated when switching on the MAG.DRIVE.

- Open the purge gas supply.
- Open the cooling water supply.
- Press the START key.

The pump runs-up. The STATUS LED is slowly flashing green. When the STATUS LED is lit permanently green the pump is in normal operation.

The backing pump and the MAG can be switched on simultaneously. In such a situation the MAG serves from the very outset as an effective baffle.

Switching off

- Press the STOP key.

The STATUS LED is fast flashing green. When the STATUS LED is off the pump has come to a standstill.

- Close the cooling water supply when the pump is switched off in order to avoid condensate formation in the pump.

The backing pump may be switched off once the MAG has stopped.

If the MAG has been used for pumping corrosive gases it should be purged with dry nitrogen for one hour before switching off. During down times of the system take care that neither ambient air nor cleaning agents enter the pump.

After a failure has occurred and has been removed, acknowledge the failure message by pressing the STOP key.

Significance of the lamps



COM (green)

Is lit if communication has been established via the interface.

STATUS (green/red)

Red, steady light	= Failure
Red, flashing	= Warning
Green, flashing (slow)	= Start delay, Acceleration
Green, flashing (fast)	= Deceleration, Kinetic buffering
Green, steady light	= Normal operation

MAIN (green)

This lamp is lit if the power is switched-on, and all of the supply voltages for operation are available.

Flashes when the power fails as long as the power supply voltages in the converter are maintained by the kinetic buffering.





Fig. 23 Function diagram START/STOP



Switch closed: START
Switch open: STOP

Fig. 24 Connecting-up example remote control

3.3 Remote control

The pump can be switched-on or off using the START/STOP keys or via control connector X14.

- X14.11 not connected = Start/Stop via the operator control panel
- Jumper X14.11-X14.10 = Start/Stop via control input X14.12

4 Plug-in control

4.1 Operation with plug-in control

Observe the general operation rules given in Section 3.1

Switching on

- Switch on the MAG.DRIVE. The display reads

Ready	
0.0 A	0 Hz

In case of corresponding connection the backing pump will be activated when switching on the MAG.DRIVE.

- Open the purge gas supply.
- Open the cooling water supply.
- Press the START key.

The pump runs-up.

Acceleration	
20.0 A	250 Hz

is displayed until the frequency setpoint has been reached. Then

Normal Operation	
1.0 A	480 Hz

is displayed.

The backing pump and the MAG can be switched on simultaneously. In such a situation the MAG serves from the very outset as an effective baffle.

Switching off

- Press the STOP key.

Deceleration	
20.0 A	400 Hz

will be displayed. When the display reads


Ready	
0.0 A	0 Hz

the pump has come to a standstill.

- Close the cooling water supply when the pump is switched off in order to avoid condensate formation in the pump.

The backing pump may be switched off once the MAG has stopped.


If the MAG has been used for pumping corrosive gases it should be purged with dry nitrogen for one hour before switching off. During down times of the system take care that neither ambient air nor cleaning agents enter the pump.



Key	Function
Esc	<ul style="list-style-type: none"> Returns to the operating display from the storage procedure without storage. Returns to the operating display from any point of the basic menu.
Mon	<ul style="list-style-type: none"> No function
Prog	<ul style="list-style-type: none"> Selects the programming menu from the operating display. Confirms to store changed parameters to the EEPROM
Enter	<ul style="list-style-type: none"> Switches forward to the next submenu
Start	<ul style="list-style-type: none"> Starts the pump (only possible if there is no fault). The start key is only active if the user is in the basic menu or in the operating display.
Stop	<ul style="list-style-type: none"> Stops the pump Returns to the operating display from the programming menu. Acknowledges a failure after the cause of the failure has been removed.
+	<ul style="list-style-type: none"> Increases a parameter value or proceeds to the next option.
-	<ul style="list-style-type: none"> Lowens a parameter value or returns to the previous option.
◀	<ul style="list-style-type: none"> Selects the programming menu from the operating display. Switches back to the last main menu.
▶	<ul style="list-style-type: none"> Selects the programming menu from the operating display. Switches forward to the next main menu.

Fig. 25 Functions of the front panel keys


Operating display



Operating status

Motor current / Actual frequency

If a critical operating status occurs this warning is displayed alternating with the operating display.



Failure message

Failure cause

Fig. 26 Display

4.2 Operating statuses

Switch-On Guard

The converter goes into the "Switch On Guard" operating status after the power is switched on and after initialization. If there is no warning or failure, it changes over into the "Ready" condition.

After a failure has been acknowledged, the converter goes into the "Switch On Guard" operating status. The failure must be acknowledged a second time, so that it then goes into the "Ready" condition.

Ready

The converter is ready and waits for the START command. All parameters can be interrogated or changed via the operator control panel or the serial interface.

The basic menu parameters (refer to 4.3, operating menu) can be scanned via the operator control panel.

Acceleration

The pump continuously accelerates with the maximum current. The acceleration time is monitored to ensure that it lies within a programmed value (refer to the menu "settings pump/Accel. Time"). If the converter hasn't reached the normal operating mode during the monitoring time, then it is shutdown with the failure message „Accel. Time“.

Normal Operation

After a programmable frequency threshold has been reached (refer to the menu "settings pump/Normal Operation"), the converter goes into the normal operation mode but the pump continues to accelerate up to the frequency setpoint.

Overload

The speed is continuously monitored and controlled. If the speed, even at maximum current, cannot be held at the setpoint, as a result of external influences, e.g. excessive gas intake, the speed reduces until the converter goes into the „Overload“ operating condition when the programmable frequency threshold is fallen below (refer to the menu "settings pump/Normal Operation"). The acceleration time is restarted. If the converter hasn't gone into the normal operating mode after the monitoring time, it is shutdown with the failure message „Failure Overload Time“.

Mains Down

If the power fails when the converter is switched on, the converter regenerates due to the pump up to a minimum frequency of < 170 Hz. When the power returns, the pump is again accelerated up to the frequency setpoint.


The acceleration time is now restarted. If the converter hasn't gone into the normal operating mode after the monitoring time, it is shutdown with the failure message „Accel. Time“.

Deceleration

After a stop command, the pump is braked down to a speed < 1 Hz as quickly as possible. A brake resistor is integrated into the converter which converts the regenerative energy into heat.

Failure

The converter was shutdown with a failure message and waits for a failure acknowledgement after the failure has been removed. The failure type can be read from the display. The failure message can be acknowledged by depressing the STOP key or via the serial interface.




Parameter:
P24 = Frequency setpoint
P25 = Factor normal operation

Fig 27 Diagram: Operation status

4.3 Operating menu

4.3.1 Basic menu


Menu item	Description	Adjustable value / option				Access
		min. value	max. value	stan- dard	Unit	
Ready	Operating display	-	-	-	-	-
Freq. Setpoint	Sets the speed for operation !! Every change is directly written into the pump's data storage and is valid immediately!!	150	480	480	Hz	r/w
Operation Hours	Total operating hours of the pump	actual value			h	r
Motor Temp.	Motor temperature	actual value			°C	r
Converter Temp.	Temperature of the power electronic	actual value			°C	r
Bearing Temp.	Temperature of the magnetic bearing	actual value			°C	r
Actual Value TMS	Temperature of the Temperature Management System	actual value			°C	r
Cooling Temp.	Cooling water temperature	actual value			°C	r
Actual PVW 13	Rotor displacement in the magnetic bearing plane VW13	actual value			%	r
Actual PVW 24	Rotor displacement in the magnetic bearing plane VW24	actual value			%	r
Actual PZ 12	Rotor displacement in the magnetic bearing axis Z12	actual value			%	r
Power	Power consumption of the drive	actual value			W	r
Software Version	Actual software version	actual value			-	r



r (read) = value can **only** be read

r /w (read/write) = value can be read and written

4.3.2 Settings converter



Menu item	Description	Adjustable value / option				Access
		min. value	max. value	standard	Unit	
Option Relay 1	Relay with change-over contact; the operator can select one of the functions described the thresholds are adjusted in the following menu items * not active when operating a MAG 2010 C	Threshold bearing temperature reached			°C	r/w
		Threshold motor current reached			A	
		Threshold frequency reached			Hz	
		No cooling water*			-	
		no purge gas*			-	
		TMS temperature o.k.*			-	
		Vent*			-	
		Start command applied			-	
		Power supply o.k.			-	
		Pump standstill			-	
Option Relay 2	The settings of the option relays 2 to 4 can be changed similar to option relay 1 but they cannot be stored in the pump's data storage device. After each power off the option relays 2 to 4 are in the default state.	Start command applied			-	
Option Relais 3		Power supply o.k.			-	
Option Relais 4		Pump standstill			-	
Threshold	Threshold bearing temp. for option relay	0	100	60	°C	r/w
Threshold	Threshold motor current for option relay	0	20	10	A	r/w
Threshold	Threshold frequency for option relay	0	480	300	Hz	r/w
Analog Output	Analog output 0...10V; the operator can select one of the functions described	Motor current;				r/w
		20 A = 10Vxscale factor			V	
		Act. frequency ;				
		500 Hz = 10Vxscale factor			V	
		Bearing temp.;				
		100 °C = 10Vxscale factor			V	
		Actual PVW13;				
Scale Factor	Scale factor for the analog output	100% = 10Vxscale factor			V	r/w
		Actual PVW24;				
		100% = 10Vxscale factor			V	
		Actual PZ12;				
Analog Input 2	Analog input 0...10V ; optionally frequency setpoint via analog input 2 (10V = max. frequency setpoint)	No function			-	r/w
		Function frequency setpoint			-	
Start Delay	Waiting time between start command and acceleration	0	1200	0	s	r/w
Display	Display language	English			-	r/w
		German			-	
Bus Address	Bus address for the converter by operation via serial interface RS232/485	0	31	0	-	r/w

r (read) = value can **only** be read


r /w (read/write) = value can be read and written

4.3.3 Settings pump


Menu item	Description	Adjustable value / option				Access
		min. value	max. value	stan- dard	Unit	
Normal Operation	Threshold for normal operation corresponding to the frequency setpoint	35	99	95	%	r/w
Max. Accel. Time	Monitor time for acceleration and overload	600	3600	1000	s	r/w
Pump Type	Displays the installed pump type	Installed pump type			-	r

r (read) = value can **only** be read

r /w (read/write) = value can be read and written



4.3.6 Total view of the menu



5 Maintenance

The MAG is nearly maintenance-free. Wear only occurs at the touch-down bearings when hard shocks have to be supported or when the pump frequently runs down without venting.

Maintenance is also required after removing the bearing cable during operation of the pump.

Under these conditions the rotor can not be controlled by the magnet bearing and the pump will have a full run down on the touch down bearing.

The rotor has to be changed after 40,000 hours of operation or after 5 years.

Depending on the installation site the converter may collect grime (dust, moisture) on the inside. Such contamination may lead to malfunctions, overheating or short circuits. Therefore the converter must be cleaned after 5 years.

Only the Leybold service can change the rotor and clean the converter.

5.1 Removing the pump from the system

MAG which have been used in semiconductor processes are contaminated by semiconductor process gases. Most of these gases form acids when exposed to moist air which causes serious corrosion damage to the pump.

To prevent corrosion damage during storage and shipping, use the seal kit.

Failure to seal a contaminated MAG voids the warranty.

The seal kit contains the following

- dry cartridge,
- plastic cap for forevacuum connection flange and purge gas connector
- plastic adhesive film and
- aluminum cover and screws for the high-vacuum connection flange.

Proceed as follows to seal the turbomolecular pump immediately after removing it from your process.

Purge the pump for two hours with the backing pump running. This helps to remove a large quantity of the process gases from the pump. We recommend purging the pump via the intake flange and the purge valve with approx. 200 sccm.

Press the STOP button at the MAG.DRIVE and wait until the pump has come to a standstill.

Afterwards turn the mains switch to the „0“ position.

The cables between the MAG and MAG.DRIVE may be disconnected only after the MAG has come to a full still-stand **and** the mains is switched off.

Warning



When the pump has been pumping hazardous gases, ensure that proper safety precautions are taken before opening the intake or exhaust connections.



Use gloves or protective clothing to avoid skin contact with toxic or highly corrosive substances. Work under a fume hood if available.



Disconnect the cables from the pump.

Disconnect the forevacuum line.

Disconnect the cooling water lines. Remaining cooling water may flow out. Protect all parts below.

Remove 10 of the 12 bolts which hold the intake flange. The 2 remaining bolts must be directly opposite.

Support the pump with a lift-truck at the base plate and remove the 2 remaining bolts.

Clean the intake and forevacuum connection flange as necessary for good adhesion of tape.


Place the dry cartridge into the forevacuum port. Don't use loose crystals.

Firmly seal all ports with plastic adhesive film.

Cover the forevacuum connection port with its plastic cap.

Seal the high-vacuum connection flange with the cover and the screws.

Pack the pump so that it may not be damaged during transportation. Particularly protect the flanges, the cooling water connectors and the current feedthrough.



5.2 Service at Leybold's

If you send a pump to Leybold indicate whether the pump is free of substances damaging to health or whether it is contaminated. If it is contaminated also indicate the nature of hazard. To do so, you must use a pre-printed form which we shall send to you upon request.

A copy of this form is printed at the end of the Operating Instructions: „Declaration of Contamination of Vacuum Equipment and Components“.

Either fasten this form at the pump or simply enclose it to the pump.

Don't pack the form with the pump into the PE bag.

This declaration of contamination is necessary to comply with legal requirements and to protect our staff.

Leybold must return any pump without a declaration of contamination to the sender's address.

6 Troubleshooting

In case of a malfunction, the MAG will be braked and the first line of the display shows

FAILURE

Malfunction messages can be cancelled once the pump has come to a stop and after the malfunction has been rectified; do so with the STOP function (button or serial interface).

Warning



The MAG shall be stopped completely and the mains power cord detached before you open the MAG.DRIVE. Since dangerous voltages may nonetheless be encountered, the housing must be opened only by a qualified electrician.

6.1 Warning messages

Warning Message on Display	Possible Cause	Measures
Motor Temp. Temperature sensor inside the motor reads a higher temperature value than the warning threshold (100 °C).	Motor temperature exceeds the warning threshold e.g. due to a high gas load. Drive failure or internal converter failure.	Take the actual motor temperature reading from the display; see Section 4.3.1. Reduce gas load. If the warning persists contact Leybold service. Contact Leybold service.
Bearing Temp. Temperature sensor inside the pump reads a higher temperature value than the warning threshold (68 °C).	Cooling water flow too low or cooling water temperature too high. Frequent acceleration and deceleration of the pump.	Apply cooling water according to specifications. Check cooling water tubes for deposits. See also Section 2.6. Allow pump to cool down between the cycles.
Converter Temp. Temperature sensor inside of the converter reads a higher temperature value than the warning threshold (65 °C).	Frequent acceleration and deceleration of the pump. No sufficient air circulation.	Allow converter to cool down between the cycles. Refer to Section 2.8 for the correct mounting of the converter in a rack; max. ambient temperature 45 °C.
Unbalanc. PVW13 Unbalanc. PVW24 Unbalanc. PZ12 A rotor displacement exceeding the warning threshold occurred. The code designates the affected axis.	Mechanical shocks, perhaps due to tool maintenance. Shock venting. Converter failure.	If warning message persists contact Leybold service. Check the chamber pressure during operation. Contact Leybold service.
Overload The rotational speed dropped below normal operation frequency.	Backing pressure too high during operation. Parameters „Normal Operation“ are not set correctly.	Reduce backing pressure. Additionally, check process gas flow. Set parameter „Normal Operation“ to default 95%. Refer also to Section 4.3.3.
Mains Down The converter is in the generator mode.	Mains interrupted or converter switched off during operation of the pump.	Reconnect converter to the mains. Switch on the converter.
Protection The pump drive is blocked.	Emergency off active.	Deactivate „Emergency off“ via control plug X14.

6.2 Failure messages

Failure Message on Display	Possible Cause	Measures
Motor Temp. Temperature sensor inside the motor reads a higher temperature value than the failure threshold (100 °C).	Motor temperature exceeds the failure threshold e.g. due to a high gas load. Motor temperature sensor defective. BEARING cable or connector damaged. Converter failure.	Acknowledge failure message. Take the actual motor temperature reading from the display; see Section 4.3.1. Reduce gas load. If the warning persists contact Leybold service. Step 1: Check pump (temperature sensor) Check pump connector X23. In particular measure resistance between pins X23/x and X23/w. The resistance is typically $2\text{k}\Omega \pm 1\%$. In case of abnormal values ($> 3.4\text{ k}\Omega$) are measured contact Leybold service. Step 2: Check BEARING cable If step 1 was successful do the following: Check BEARING cable for bent pins Measure the resistance between pins X20/x and X20/w with the cable connected to the pump. The resistance is typically $2\text{k}\Omega \pm 1\%$. Replace the cable if it is damaged or in case the measurement of the resistance shows abnormal values ($> 3.4\text{ k}\Omega$) now. Contact Leybold service.
Bearing Temp. Temperature sensor inside the pump reads a higher temperature value than the failure threshold (70 °C).	Cooling water flow too low or cooling water temperature too high. Frequent acceleration and deceleration of the pump. Pt 100 (temperature sensor bearing) damaged. BEARING cable or connectors damaged. Converter failure.	Apply cooling water according to specifications. Check cooling water tubes for deposits. See also Section 2.6. Allow pump to cool down between the cycles. Step 1: Check pump (temperature sensor) Check pump connector X23. In particular measure resistance between pins X23/v and X23/u as well as between pins X23/v and X23/t. The resistance is typically between $110\ \Omega$ and $130\ \Omega$ (20 °C to 70 °C). In case abnormal values are measured contact Leybold service. Step 2: Check BEARING cable If step 1 was successful do the following: Check BEARING cable for bent pins Measure the resistance between pins X20/v and X20/u as well as between pins X20/v and X20/t with the cable connected to the pump. The resistance is typically between $110\ \Omega$ and $130\ \Omega$ (20 °C to 70 °C). Replace the cable if it is damaged or in case the measurement of the resistance shows abnormal values now. Contact Leybold service.
Converter Temp. Temperature sensor inside of the converter reads a higher temperature value than the failure threshold (90 °C).	Frequent acceleration and deceleration of the pump. No sufficient air circulation. Converter failure.	Allow converter to cool down between the cycles. Refer to Section 2.8 for the correct mounting of the converter in a rack; max. ambient temperature 45 °C. Contact Leybold service.

Failure Message on Display	Possible Cause	Measures
Overload PZ 12 Overload PV 13 Overload PW 24 An abnormal displacement of the rotor occurred at frequencies between 0 and 5 Hz. The code designates the affected axis.	Mechanical shocks, possibly due to tool maintenance when the rotor stands still. Pump is still protected with transport seal on power up. BEARING cable or connector damaged.	Acknowledge failure message and restart the pump. If failure message persists contact Leybold service. Remove transport seal; see Section 2.4. Check BEARING connector and cable for bent pins. Contact Leybold service if the cable is damaged.
MB An abnormal displacement of the rotor occurred at frequencies between 146 Hz and 480 Hz.	Mechanical shocks, possibly due to tool maintenance. Shock venting. Converter failure.	Acknowledge failure message and restart the pump. If failure message persists contact Leybold service. Check the chamber pressure during the operation. Refer to Section 3.1 for correct venting of the pump. Contact Leybold service.
PK Communication Converter does not communicate with the memory chip inside of the pump.	BEARING cable not connected or damaged. Memory chip inside of magnetic bearing cartridge malfunctioning.	Check BEARING connector and cable for damages or bent pins. Contact Leybold service if the cable is damaged. Contact Leybold service.
MB-Code Wrong Magnetic bearing controller does not work.	Converter failure.	Contact Leybold service.
Starting Time The frequency has not reached 40 Hz 2 minutes after the start command was applied.	Backing pressure too high during start-up. Rotor blocked.	Reduce backing pressure. Check if the rotor rotates freely. Contact Leybold service if the rotor is damaged or blocked.
Accel. Time The pump does not reach the normal operation frequency after the set maximum acceleration time.	Backing pressure too high during start-up. Parameter „Accel. Time“ is not set correctly.	Reduce backing pressure. Set parameter „Accel. Time“ to default 1000 s; see Section 4.3.3.
Overload Time The rotational speed has dropped below normal operation frequency and stays there for longer than the maximum „Accel. Time“.	Backing pressure too high during operation. Parameters „Accel. Time“ or „Normal Operation“ are not set correctly.	Reduce backing pressure. Additionally check process gas flow. Set parameter „Normal Operation“ to default 95 % and parameter „Accel. Time“ to default 1000 s; see Section 4.3.3.
Shutdown Freq. Rotational speed dropped below the shutdown frequency threshold (140 Hz).	Backing pressure too high during operation.	Reduce backing pressure. Additionally check process gas flow.

Failure Message on Display	Possible Cause	Measures
Bearing Temp. SC The magnetic bearing temperature sensor reads a temperature lower than 1 °C.	Temperature sensor Pt 100 short-circuited. BEARING cable short-circuited. Converter failure.	Repeat step 1 of „failure Bearing Temp.“. Contact Leybold service if the resistance of the sensor is less than 100 Ω. Repeat step 2 of „failure Bearing Temp.“. Contact Leybold service if the resistance of the sensor is less than 100 Ω. Contact Leybold service.
Motor Temp. SC The motor temperature sensor reads a temperature lower than 1 °C.	Temperature sensor KTY short-circuited. BEARING cable short-circuited. Converter failure.	Repeat step 1 of „failure Motor Temp.“. Contact Leybold service if the resistance of the sensor is less than 1.62 kΩ. Repeat step 2 of „failure Motor Temp.“. Contact Leybold service if the resistance of the sensor is less than 1.62 kΩ. Contact Leybold service.
Connection pump	BEARING cable not connected. Converter failure.	Check if the BEARING cable is connected to the pump and the converter. Acknowledge failure message. Contact Leybold service.
Frequency XX* Abnormal motor current or frequency *XX is a code no. between 43 and 55. It helps the Leybold service to find the cause of the failure.	The rotor frequency exceeds 515 Hz. Converter failure.	Acknowledge failure message. If failure persists contact Leybold service. Contact Leybold service.
No Motor Current	On START command: DRIVE cable not connected or connectors damaged. Resultant message after activating „Emergency off“. DRIVE cable interrupted during operation of the MAG.	Check cables and connectors, straighten pins if required. Deactivate „Emergency off“ via control plug X14 and acknowledge failure message. Reconnect or replace DRIVE cable.

6.3 Malfunctions

Malfunction	Possible Cause	Measures
Converter dead, LED „mains“ does not light up after switching on.	No power supply. Fuse F1 blown or converter failure.	Check the line voltage. Contact Leybold service.
Display malfunction, confusing messages. No reaction when pressing keys.	Converter failure.	Switch the converter off and on again. If the converter still malfunctions contact Leybold service.
Vacuum chamber pressure rises above normal backing pressure while the pump is stopped.	Purge gas or venting valve open or malfunctioning.	Check and replace valve if required.
Base pressure not reached.	Degassing surfaces of rotor and stator. If the pump was stored in a humid environment or was exposed to humid ambient air all surfaces will be covered with condensation.	Leave the pump system run for 3 to 5 hours to reach a pressure below 10^{-5} mbar.
Display blurred.	Ambient temperature too high or too low.	Operate the converter according to the specifications.

EEC Manufacturer's Declaration

in the sense of EEC Directive on Machinery 89/392/EWG, Annex IIb



We - LEYBOLD Vacuum GmbH - herewith declare that operation of the incomplete machine defined below, is not permissible until it has been determined that the machine into which this incomplete machine is to be installed, meets the regulations of the EEC Directive on Machinery.

At the same time we herewith certify conformity with EEC Directive on Low-Voltages 73/23/EWG.

When using the appropriate Leybold accessories, e.g. connector lines and when powering the pump with the specified Leybold frequency converters, the protection level prescribed in the EMC Guidelines will be attained.

Designation: Turbomolecular pump

Model: MAG W 2010 C

Catalogue number: 121 32

Applied harmonized standards:

- | | |
|---------------------|-----------|
| • EN 292 Part 1 & 2 | Nov. 1991 |
| • EN 1012 Part 2 | 1996 |
| • EN 60 204 | 1993 |

Applied national standards and technical specifications:

- | | |
|----------------|------------|
| • DIN 31 001 | April 1983 |
| • DIN ISO 1940 | Dec. 1993 |

Cologne, October 1, 1998

A handwritten signature in black ink, appearing to read 'Dr. Mattern-Klosson', written over a dashed horizontal line.

Dr. Mattern-Klosson, Business Area Manager
Turbomolecular pumps

Cologne, October 1, 1998

A handwritten signature in black ink, appearing to read 'Stolle', written over a dashed horizontal line.

Stolle, Design Manager
Turbomolecular pumps

EC declaration of manufacture

in accordance with Art. 4 paragraph 2 of EC directive 89/392/EEC

Document No.: **MSR 0898 / MAG.DRIVE 2000**
Manufacturer: **REFU elektronik GmbH**
Product Identification: **MAG.DRIVE 2000**
Catalog No.: **121 35, 121 36, 121 37**

The product indicated solely for fitting in another machine. Commissioning is prohibited until the conformity of the end product with EC directive 89/392/EEC has been established.

Standards applied: **EN 60204-1**
EN 61010-1

REFU elektronik GmbH
Metzingen, 1998.08.12



Harald Lautz,
Head of Business Unit OEM



Herbert Schleicher,
Manager of Developement OEM

The savety notes given in the product documentation must be observed.

EC declaration of conformity

Document No.: **NSR 0898 / MAG.DRIVE 2000**
Manufacturer: **REFU elektronik GmbH**
Product Identification: **MAG.DRIVE 2000**
Catalog No.: **121 35, 121 36, 121 37**

Herewith, we declare that this product, as a result of its design and type of construction, and the version marketed by us, correspond to the basic health and safety regulations specified in the EEC Directives.

This declaration is no longer valid if the product is modified without us being in full agreement.

The product conforms to the EEC Low-Voltage Directive (73/23/EEC).

Standards applied: **EN 61010-1**

Display the CE-mark: **August 1998**



REFU elektronik GmbH
Metzingen, 1998.08.12

A handwritten signature in black ink, appearing to be 'H. Lautz', written over a dotted horizontal line.

Harald Lautz,
Head of Business Unit OEM

A handwritten signature in black ink, appearing to be 'H. Schleicher', written over a dotted horizontal line.

Herbert Schleicher,
Manager of Development OEM

The safety notes given in the product documentation must be observed.

Factory certificate

Document No.: **EMV 0898 / MAG.DRIVE 2000**
Manufacturer: **REFU elektronik GmbH**
Product Identification: **MAG.DRIVE 2000**
Catalog No.: **121 35, 121 36, 121 37**

The named product, when put to its intended use, satisfies the requirements of Directive 89/336/EEC concerning electromagnetic compatibility.


The applicable measurements were made taking into account the following standards:

EN 50081 Part 2
EN 50082 Part 2

Note

Attention must be paid to the information provided on proper installation with respect to electromagnetic compatibility and to other pertinent notes in the documentation supplied with the product, as well as to the relevant information concerning electrical connection.

REFU elektronik GmbH
Metzingen, 1998.08.12



Harald Lautz,
Head of Business Unit OEM



Herbert Schleicher,
Manager of Development OEM

Declaration of Contamination of Vacuum Equipment and Components

The repair and/or service of vacuum equipment and components will only be carried out if a correctly completed declaration has been submitted. Non-completion will result in delay. The manufacturer could refuse to accept any equipment without a declaration.

This declaration can only be completed and signed by authorized and qualified staff.

1. Description of Vacuum Equipment and Components

- Equipment type/model: _____
- Code No.: _____
- Serial No.: _____
- Invoice No.: _____
- Delivery date: _____

2. Reason for Return

3. Condition of the Vacuum Equipment and Components

- Has the equipment been used?
yes ☐ no ☐
- What type of pump oil/liquid was used? _____
- Is the equipment free from potentially harmful substances?
yes ☐ (go to Section 5)
no ☐ (go to Section 4)

4. Process related Contamination of Vacuum Equipment and Components:

- toxic yes ☐ no ☐
- corrosive yes ☐ no ☐
- explosive*) yes ☐ no ☐
- biological hazard*) yes ☐ no ☐
- radioactive*) yes ☐ no ☐
- other harmful substances yes ☐ no ☐

*) Vacuum equipment and components which have been contaminated by biological explosive or radioactive substances, will not accepted without written evidence of decontamination!

Please list all substances, gases and by-products which may have come into contact with the equipment:

Trade name Product name Manufacturer	Chemical name (or Symbol)	Dangerous material class	Measures if spillage	First aid in case of human contact
1.				
2.				
3.				
4.				
5.				

5. Legally Binding Declaration

I hereby declare that the information supplied on this form is complete and accurate. The despatch of the contaminated vacuum equipment and components will be in accordance with the appropriate regulations covering Packaging, Transportation and Labelling of Dangerous Substances.

Name of organisation or company: _____

Address: _____ Post code: _____

Tel.: _____

Fax: _____ Telex: _____

Name: _____

Job title: _____

Date: _____ Company stamp: _____

Legally binding signature: _____

Form TMP-1 ... Turbopump Field Failure Report

Field Service IR No.: _____ RMA No. (if returning to factory): _____

Service Center: _____

Customer: _____

Turbopump Model: _____ Turbopump Pump Part Number: _____

Turbopump Serial Number: _____

Complaint: _____

Process: _____

OEM Equipment Name and Model: _____

Process Gas: _____

Was the turbopump replaced? ☐ Yes; ☐ No.

If yes, replacement pump P/N: _____ replacement pump S/N: _____

Date Installed: _____ Date Removed: _____

Date Received: _____

Date Examined: _____ Examined by: _____

Received Condition: _____

Findings: _____

Cause of Failure: _____

Recommendations: _____

Remarks/Questions: _____

LEYBOLD VACUUM



Operating Instructions for MAG 2000 series

Operating Instructions	Valid for pumps	Valid for Converters
GA 05.130/1.02 (December 1997)	MAG W 1600 C, CT (Operation diagram & pumping speed curve missing) MAG 2000 C, CT MAG W 2000 C, CT	MAG.DRIVE L MAG.DRIVE L2 (Troubleshooting incomplete)
GA 05.130/2.02 (February 1998)	MAG W 1600 C, CT MAG 2000 C, CT MAG W 2000 C, CT	MAG.DRIVE L MAG.DRIVE L2 (Troubleshooting incomplete)
GA 05.130/3.02 (May 1998)	MAG 1600 C, CT MAG W 1600 C, CT MAG 2000 C, CT MAG W 2000 C, CT	MAG.DRIVE L MAG.DRIVE L2
GA 05.135/1.02 (August 1998)	MAG 1600 C, CT MAG W 1600 C, CT MAG 2000 C, CT MAG W 2000 C, CT	MAG.DRIVE 2000
GA 05.136/1.02 (July 1998)	MAG W 2010 C	MAG.DRIVE 2000
GA 05.136/2.02 (October 1998)	MAG W 2010 C	MAG.DRIVE 2000



LEYBOLD VAKUUM GmbH

Bonner Strasse 498 (Bayenthal)

D-50968 Cologne

Tel.: + 49 (221) 347-0

Fax: + 49 (221) 347-1250

<http://www.leyboldvac.de>

e-mail: documentation@leyboldvac.de